Aluminum Fence Slats / Louver Installation

Our aluminum fence slats can be used for either 100% privacy or as a louver in order to guide air into your fenced in area.

- 1. Measure you fence in order to know what size slats to buy. If you have a 5' high fence, you will want to order a 5' high slats. The 5' high slats are a true 60" tall, so you will need to cut them to size.
- 2. Cut the panel to the correct height using a miter saw or a band saw. If using a miter saw, reverse the blade in order to avoid chipping the plastic. You can also use tin snips if you want to cut the slats by hand.





- 3. Simply snap the slats onto the pickets. Once the slat is has been firmly snapped onto the picket, the louver panel can be easily turned.
- 4. Because the slats is designed to overlap the next slat in the middle of the space between pickets, there is typically a space on the fence panels on





both sides of every fence section. This space can be closed with an extension clip. The extension clip simple slips on the end of the last fence slat and makes the end of the section.

Note: The picture shows the aluminum fence slats WITHOUT extension clips.

5. Now enjoy your new privacy with aluminum fence slats.